


PARTS MANUAL EEFS107A

**AEC GROUP
3600 W. CARRIAGE DRIVE
SANTA ANA CA. 92704
Ph:877/906-1395**

PARTS MANUAL EEFS107A



INTRUMENT PANEL LAYOUT

1	2218-21-40-3	GAUGE, 0-160 PSI X 2 1/2" X 1/4" MPT
2	2121-39-31-1	NEEDLE VALVE ASSY(PRESSURE ADJUST)
3	2121-32-21-1	PURGE VALVE ASSY
4	3090-11-11-0	POWER SWITCH W/ACTUATOR 0-1
5	3165-00-00-1	TIMER, 0-60 MINUTES
6	5103-20-01-1	INSTRUMENT PANEL (EEFS107A)

PARTS MANUAL EEFS107A




**GAUGE 0-160 PSI X 2 ½"OD X ¼"MPT
2218-21-40-3**



**POWER SWITCH W/ACTUATOR 0-1
3090-11-11-0**


PARTS MANUAL EEFS107A



NEEDLE VALVE ASSY (PRESSURE ADJUST) 2121-39-31-1

1	2121-39-30-1	NEEDLE VALVE
2	2354-31-14-1	FITTING, POLY ¼" MPT X 90 X 3/8" HOSE
3	2554-54-22-1	ELBOW, ¼" FPT X ¼" FPT

PARTS MANUAL EEFS107A



PURGE VALVE ASSY. 2121-32-21-1

1	2121-32-20-1	PURGE VALVE
2	2354-31-13-1	FITTING POLY 1/4" MPT X 90 X 1/4" HOSE
3	2354-41-12-1	TEE STREET 1/4" FPT X 1/4" MPT X 1/4" FPT
4	2354-40-24-1	FITTING 1/4" FPT X 3/8" BARB
5	2461-33-30-1	TEE STREET 1/4" FPT X 1/4" MPT X 1/4" MPT
6	2354-31-14-1	FITTING POLY 1/4" MPT X 90 X 3/8" HOSE
7	2354-32-14-1	FITTING POLY 1/4" MPT X TEE RUNNING X 3/8" HOSE
8	2554-54-21-1	ELBOW 1/4" FPT X 1/4" MPT

PARTS MANUAL EEFS107A



**TIMER 0-60 MINUTES
3165-00-00-1**




**AUDIO SIGNAL 3-28 VDC
3160-68-12-1**

PARTS MANUAL EEFS107A



**FUSE 15 AMP/ 32V X 1 ¼" LONG(GLASS)
3051-15-30-1**




**FUSE HOLDER FOR 1 ¼" LONG FUSES
3050-21-40-0**

PARTS MANUAL EEFS107A



**CORD/CLAMP ASSEMBLY 12VDC X 12'(RED/BLACK)
3075-12-22-7**


PARTS MANUAL EEFS107A



DIAPHRAM PUMP 12VDC X 120 PSI W/EXPANSION CHAMBER ASSEMBLY 2245-21-39-3

1	2245-21-30-3	DIAPHRAM PUMP 12VDC X 120 PSI X 3/8" BARB
2	5106-21-01-1	EXPANSION CHAMBER
3	2245-21-00-0	FITTING 5/8" O-RING SEAT X 90 X 3/8" BARB FOR 2245-21-30-3
4	2140-39-50-1	CHECK VALVE 1/4" MPT X 1/4" FPT
5	0901-56-00-2	HYTRON HOSE 3/8" ID X 5/8" OD (RED)


PARTS MANUAL EEFS107A



PUMP UPGRADE KIT (GEAR TYPE) 2246-22-15-1

1	2246-22-15-0	GEAR PUMP ASSY WITH 3/8" BARB FITTINGS
2	2352-41-14-6	FITTING 1/8" MPT X 90 X 3/8" BARB NYLON
3	5108-01-00-1	CHASSIS BRACKET FOR 2246-22-15-1
4	0901-56-16-2	HOSE 5/8" OD X 3/8" ID X 15 1/2" RED
5	2354-40-14-1	FITTING 1/4" MPT X 3/8" BARB
6	2140-39-20-1	CHECK VALVE 1/4" FPT X 1/4" MPT (S/S)

PARTS MANUAL EEFS107A



RETURN LINE CHECK VALVE ASSEMBLY 2140-39-21-1

1	2354-30-24-1	FITTING POLY ¼" FPT X 3/8" HOSE
2	2140-39-20-1	CHECK VALVE ¼" FPT X ¼" MPT
3	2354-40-14-1	FITTING ¼" MPT X 3/8" BARB

PARTS MANUAL EEFS107A




**HOSE ASSEMBLY TANK TO FILTER (EEFS107A) RED
0901-56-98-2**



**HOSE ASSEMBLY FILTER TO PUMP (EEFS107A) RED
0901-56-99-2**

PARTS MANUAL EEFS107A



TANK 56oz ASSEMBLY 2261-41-21-1

1	2261-41-20-1	TANK FUEL 56oz
2	2354-30-14-1	FITTING POLY 1/4" MPT X 3/8" HOSE
3	2293-54-41-1	TANK TUBE ASSY 6.700" X 90 X 3/8" BARB
4	2291-78-11-4	CAP 1 3/4" ID TANK FUEL W/ OPEN VENT

PARTS MANUAL EEFS107A



**INLINE FILTER 3/8" BARB X 3/8" BARB
0600-01-00-0**



**QUICK DISCONNECT S/23 BODY X 1/4" MPT(VITON)
2023-13-10-2**

PARTS MANUAL EEFS107A



**PRESSURE HOSE ASSEMBLY 8' X ¼"ID (RED)
0901-54-99-2**



**RETURN HOSE ASSEMBLY 8' X ¼"ID (BLACK)
0901-54-99-1**